



Innovative Hygiene.



PH-Wert **sauer**
 ph-value **acid**

ecoENTKALKER	
Produktbeschreibung Schnellwirksamer, flüssiger Entkalker.	
Anwendung/Einsatzgebiete Entfernt mühelos auch harte, dicke Kalkablagerungen aus Geschirrspül-, Gläserspül- und Kaffeemaschinen.	
Dosierung Geschirr- und Gläserspülmaschinen: 0,5 Liter ecoENTKALKER in die Schaumpumpflasche einfüllen, mit Wasser auffüllen. Waschflotte ablassen, Kalkablagerungen einsprühen, kurz einwirken lassen, danach 2-3 mal ohne Reinigungsmittel spülen lassen. Bei Kaffeemaschinen 50 ml ecoENTKALKER mit 1 Liter heißem Wasser mischen und durchlaufen lassen, mit klarem Wasser mehrmals wiederholen.	
Verpackungseinheiten ecoENTKALKER, 14 kg Kanister Art.-Nr. 0103 ecoENTKALKER, 6 x 1,4 kg Systemflasche Art.-Nr. 01034	
Sicherheitshinweis Nicht mit alkalischen und chlorhaltigen Produkten verwenden. Die beim Umgang mit Chemikalien üblichen Schutzmaßnahmen sind zu beachten.	
Lagerung Kindersicher aufbewahren.	
Referenzen Das Entkalken mit ecoENTKALKER verlängert wesentlich die Lebensdauer der Maschine.	
Europalette 60 Kanister 14 kg 342 Systemflaschen 1,4 kg	

ecoENTKALKER	
Product Description Powerful, liquid descaler.	
Field of application/use Also removes thick lime residues from dishwashing, glasswashing and coffee machines without difficulty.	
Dosage Dish- and Glasswasher: Pour 0,5 litre ecoENTKALKER in the foam-pump-bottle, fill up with water. Drain off the wash fleet, spray in the lime residues, let it work in for a short time, then rinse 2-3 times without detergent. For coffee machines, mix 50ml ecoENTKALKER with 1 litre of hot water and let it run through the coffee machine, repeat a few times with clear water.	
Wrapping units ecoENTKALKER, 14 kg Can Art.-No. 0103 ecoENTKALKER, 6 x 1.4 kg System bottle Art.-No. 01034	
Safety information Do not use together with alkaline and chloride containing products. Follow the normal precautions while using chemicals.	
Storage Keep container closed. For quality reasons store at room temperature. Keep away from children.	
References Descaling with ecoENTKALKER basically prolongs the life time of the machine.	
Europalette 60 Cans 14 kg 342 System bottles 1,4 kg	